

PRODUCT INFORMATION



PFF AQUACOTE

A single component acrylic and polyurethane water borne lacquer. Tough and fast drying AQUACOTE is a very stable and easy to use lacquer that exceeds BS7044 (part 4) for wear resistance.

DESCRIPTION

A non-toxic, non-hazardous lacquer with extremely low odour and high coverage rate per litre. An all-purpose lacquer for floors, interior woodwork and as a base coat for AQUACOTE GOLD on soft wood and on woods with a high Tannin content.

WHERE TO USE

Use on new and existing wood floors and interior woodwork, ideal for low to medium traffic areas such as living rooms and bedrooms. AQUACOTE is suitable for refinishing most types of factory pre-finished wood and laminate wood floors. Do not use in areas with a high moisture content such as bathrooms.

FEATURES

Available in 5lt packs in gloss and satin finishes AQUACOTE is a very easy to use lacquer. A wide range of application methods makes it easy for any user to get great results.

FULL APPLICATION INSTRUCTIONS ON REVERSE



SPECIFICATIONS

Type	:	Single component acrylic based water-soluble lacquer in a polyurethane dispersion.
Coverage	:	Hardwood three coats 4m ² /litre. Softwood four coats 3m ² /litre.
Resistance to Wear	:	Medium.
Resistance to Solvents	:	Medium.
Application	:	Brush, lambs wool or synthetic applicator, roller, paint pad.
Drying Times	:	Surface dry 35 minutes. Hard dry 1 to 2 hours. Light use 6 hours. Fully cured 7 days.
Cleaning	:	Water.
Flammability	:	Non Flammable
VOC	:	Low (0.3 to 24.99%).
Safety Data Sheet	:	050

PRODUCT CODES

PSTK	Description	Case Qty	Case Weight
15042	Aquacote 5lt Gloss	2	11.28kg
15052	Aquacote 5lt Satin	2	11.28kg
15140	Floor Finish Brush 10cm	20	2.58kg
15150	Tack Rag	25	0.70kg

Matt finish and 10lt packs available to special order.

IMPORTANT INFORMATION

PFF AQUACOTE will dry on and adhere to most types of wood surfaces, however, care must be taken to remove all traces of grease, fats and polish. ALWAYS test for compatibility before full application. DO NOT apply below an ambient temperature of 8°C. For help and information contact the FLOOR TEAM helpline.

COVERAGE

HARDWOOD : Three coats 5 litres covers approximately 20m²
SOFTWOOD : Four coats 5 litres covers approximately 15m²

PREPARATION OF SURFACES

The surface MUST be absolutely clean, dry and free from grease, fats and polish. Old varnish must be lightly sanded using 120 grit or finer sandpaper. If the wood was previously wax polished, clean thoroughly with a lint free cloth and a little white spirit before the final sanding. Allow the white spirit to dry thoroughly then give the wood a final light sanding. Remove all traces of dust by first vacuuming then wiping over with a FLOOR TEAM TACK RAG.

TESTING

Test for compatibility before use. Test coat on a small area with 3 to 4 coats according to appearance required, carefully following the APPLICATION instructions below. If any coat fails to dry properly DO NOT apply to the whole floor or wood surface, contact the FLOOR TEAM helpline for advice. PFF AQUACOTE is an acrylic lacquer, which is milky in appearance and dries virtually clear. Some woods may lighten on application, always test colour before full application.

APPLICATION

Apply in well-ventilated conditions, which are dry and warm, not damp or humid. Shake bottle well before use; pour into a clean plastic paint tray or pot. Apply using a clean FLOOR TEAM FLOOR FINISH BRUSH or medium weight white bristle brush. Apply liberally and allow the PFF to flow across the surface and find its natural level. Excessive brushing is not necessary, as the PFF will flow easily.

Allow the PFF to dry hard, normally 2 hours and then apply the next coat as required. Lightly sand after the first coat using 180 grit or finer sand paper. Sand between each coat for an exceptionally fine finish or if the time between coats is more than 3 hours. Vacuum and TACK RAG between coats to keep the surface free from dust.

After the last coat has been applied allow the PFF to cure for as long as possible before use - ideally overnight although the floor may be walked on in stocking feet 6 hours after it has dried hard. Avoid placing or moving heavy furniture and objects on the floor or surface, again for as long as possible. Full cure is achieved after 7 days.

MAINTENANCE

Sweep or vacuum regularly to remove grit and clean using a damp mop. PFF does not need polishing. Scuffmarks may be removed using a non-abrasive cream cleaner.

HELPLINE

For help and information on sanding and finishing your floor or other wood surfaces call the FLOOR TEAM helpline in the UK on Tel: 01923 332424 Fax: 01923 232425 or E-mail: floorteam@hiretech.co.uk

MADE IN UK

Floor Team and Hiretech are registered trademarks of Hire Technicians Group Ltd.

Aquacote is a registered trademark of Barfords.

The specifications of the products described in this document are subject to change without prior notice.