

HIRETECH SPARE PARTS LIST

HTF-2 Floor Sander - Jul 2003

Please note this product is discontinued and some parts may no longer be listed and/or available. If you cannot find the part you are looking for please contact your local Hiretech reseller for support.

| REF | PSTK | Description | Pack Qty | Notes |
|-----|--------|---------------------------------------|----------|-------|
| 001 | 011600 | Switch 220/240 Volt (Bias Off) | 1 | |
| 001 | 011610 | Switch 110/120 Volt (Bias Off) | 1 | |
| 002 | 030425 | Housing Switch Assembly | 1 | |
| 003 | 030630 | Stop Rubber | 1 | |
| 004 | 030920 | Screw | 7 | |
| 005 | 031870 | Grip Hand | 2 | |
| 006 | 010270 | Washer Lock | 5 | |
| 007 | 030640 | Lamp Neon 110/120 Volt | 1 | |
| 007 | 030650 | Lamp Neon 220/240 Volt | 1 | |
| 008 | 030950 | Lead Neon | 2 | |
| 009 | 101206 | Nut Lock | 1 | |
| 010 | 101205 | Strain Relief | 1 | |
| 011 | 030660 | Cable Main Assembly 110 Volt (NA) | 1 | |
| 011 | 030670 | Cable Main Assembly 220/240 Volt (UK) | 1 | |
| 011 | 030680 | Cable Main Assembly 110 Volt (UK) | 1 | |
| 011 | 030690 | Cable Main Assembly 220 Volt (EEC) | 1 | |
| 011 | 030700 | Cable Main Assembly 220/240V (AUS) | 1 | |
| 012 | 030910 | Tube Handle Assembly | 1 | |
| 013 | 962345 | Screw | 10 | |
| 015 | 164508 | Hook Cable | 1 | |
| 016 | 980197 | Washer | 1 | |
| 017 | 920148 | Nut | 1 | |
| 018 | 030930 | Handle Cable (NA) | 1 | |
| 018 | 030940 | Handle Cable | 1 | |
| 018 | 031000 | Handle Cable 110 Volt (UK) | 1 | |
| 019 | 101220 | Strain Relief Handle Cable | 1 | |
| 019 | 163804 | Strain Relief Handle Cable (NA) | 1 | |
| 020 | 911046 | Body Twist Lock | 1 | |
| 021 | 010210 | Screw | 4 | |
| 022 | 031400 | Base Twist Lock | 1 | |
| 023 | 031910 | Nut | 1 | |
| 024 | 030450 | Clamp Handle | 1 | |
| 025 | 030042 | Handle Frame | 1 | |
| 026 | 031790 | Pin Pivot | 2 | |
| 027 | 031160 | Screw | 2 | |
| 028 | 031900 | Bolt | 1 | |
| 029 | 031800 | Bush Bearing | 2 | |
| 030 | 030222 | Latch | 1 | |
| 031 | 031810 | Screw | 1 | |
| 032 | 031890 | Washer | 1 | |
| 033 | 031880 | Spacer Latch Pivot | 1 | |
| 034 | 031820 | Screw | 1 | |
| 035 | 031840 | Spring Latch Return | 1 | |
| 036 | 031830 | Cover Screw | 1 | |
| 037 | 031850 | Screw | 2 | |
| 039 | 030550 | Washer | 2 | |
| 046 | 030030 | Housing Motor | 1 | |
| 047 | 030022 | Housing Gear | 1 | |
| 048 | 030010 | Housing Lower | 1 | |
| 049 | 031090 | Screw | 6 | |
| 050 | 030270 | Window Lamp | 1 | |
| 051 | 031130 | Nut | 16 | |
| 052 | 031120 | Screw | 16 | |
| 053 | 030360 | Brush Set | 1 | |
| 054 | 030350 | Bumper | 1 | |

Hire Technicians Group Ltd

Chalk Hill House, 8 Chalk Hill, Watford, Herts WD19 4BH, UK

T: +44 (0)1923 332424 F: +44 (0)1923 332425 E: sales@hiretech.biz

HI RETECH SPARE PARTS LIST

HTF-2 Floor Sander - Jul 2003

Please note this product is discontinued and some parts may no longer be listed and/or available. If you cannot find the part you are looking for please contact your local Hiretech reseller for support.

| REF | PSTK | Description | Pack Qty | Notes |
|-----|--------|--------------------------------|----------|---|
| 055 | 030300 | Support Bag (check Serial No.) | 1 | Check serial number, fits machines from serial number 00328 220/240V and 00491 110/120V |
| 056 | 031010 | Bolt | 4 | |
| 057 | 031020 | Wing Nut | 4 | |
| 058 | 030390 | Clamp Abrasive | 2 | |
| 059 | 030400 | Bush | 2 | |
| 060 | 030370 | Sanding Block | 1 | |
| 061 | 030380 | Sanding Block Abrasive Pad | 1 | |
| 062 | 030790 | Screw | 4 | |
| 063 | 030060 | Retainer Wheel | 1 | |
| 064 | 030320 | Housing Eccentric | 1 | |
| 065 | 030070 | Wheel | 2 | |
| 067 | 031420 | Exhaust Guard | 1 | |
| 068 | 031430 | Ring Retainer | 1 | |
| 080 | 030990 | Lead Motor | 1 | |
| 081 | 010750 | Brush Shunt | 2 | |
| 082 | 010170 | Brush Block Assembly | 1 | |
| 083 | 010190 | Screw | 4 | |
| 084 | 010200 | Washer | 4 | |
| 086 | 010220 | Screw and Washer Set | 4 | |
| 088 | 010180 | Brush Motor | 4 | |
| 089 | 010230 | Brush Spring | 4 | |
| 090 | 032000 | Field 110/120 Volt HTF | 1 | |
| 090 | 032010 | Field 220/240 Volt HTF | 1 | |
| 091 | 010290 | Baffle | 1 | |
| 092 | 010300 | Screw | 3 | |
| 093 | 010260 | Washer Clamp | 2 | |
| 094 | 010280 | Screw | 2 | |
| 095 | 010600 | Spring Load | 1 | |
| 096 | 010320 | Bearing | 2 | |
| 097 | 010330 | Armature 110/120 Volt | 1 | Fitted with bearing PSTK: 010320. Kit contains PSTK: 010420 x 1, PSTK: 000350 x 2, PSTK: 010320 x 1 |
| 097 | 010340 | Armature 220/240 Volt | 1 | Fitted with bearing PSTK: 010320. Kit contains PSTK: 010420 x 1, PSTK: 000350 x 2, PSTK: 010320 x 1 |
| 098 | 010350 | Key | 3 | |
| 099 | 010360 | Fan Motor | 1 | |
| 100 | 010370 | Gasket | 1 | |
| 101 | 010380 | Plate Exhaust | 1 | |
| 102 | 010390 | Fan Intake | 1 | |
| 103 | 010400 | Ring Retainer | 1 | |
| 104 | 010410 | Spacer Bearing | 1 | |
| 105 | 010420 | Seal | 1 | |
| 106 | 010430 | Ring Retainer | 1 | |
| 107 | 031520 | Spacer Pulley | 1 | |
| 108 | 030180 | Pulley Drive | 1 | |
| 110 | 010010 | Screw | 4 | |
| 111 | 030090 | Cover Motor | 1 | |
| 112 | 011840 | Insert Bearing | 1 | |
| 113 | 031280 | Bush Insulator | 1 | |
| 114 | 031070 | Lead Ground (Earth) | 1 | |

Hire Technicians Group Ltd

Chalk Hill House, 8 Chalk Hill, Watford, Herts WD19 4BH, UK

T: +44 (0)1923 332424 F: +44 (0)1923 332425 E: sales@hiretech.biz

HIRETECH SPARE PARTS LIST

HTF-2 Floor Sander - Jul 2003

Please note this product is discontinued and some parts may no longer be listed and/or available. If you cannot find the part you are looking for please contact your local Hiretech reseller for support.

| REF | PSTK | Description | Pack Qty | Notes |
|-----|--------|---|----------|--|
| 115 | 031040 | Lead Lamp/Ballast | 1 | |
| 116 | 031050 | Lead Lamp/Twist Lock | 1 | |
| 117 | 031060 | Lead Ballast/Twist Lock | 1 | |
| 118 | 030710 | Ballast Start 220/240 Volt | 1 | |
| 118 | 030720 | Ballast Start 110/120 Volt | 1 | |
| 119 | 163838 | Screw | 2 | |
| 121 | 030280 | Plate Lamp | 1 | |
| 122 | 030730 | Holder Lamp | 1 | Discontinued contact your local reseller for information |
| 123 | 030760 | Screw | 3 | |
| 124 | 030750 | Lamp | 1 | |
| 125 | 030740 | Screw | 2 | |
| 126 | 031450 | Screw | 4 | |
| 127 | 030820 | Screw | 7 | |
| 128 | 031300 | Plug Bearing | 1 | |
| 129 | 030480 | Clip | 2 | |
| 130 | 030490 | Clip | 2 | |
| 131 | 030470 | Bearing | 1 | |
| 132 | 030130 | Shaft Drive | 1 | |
| 133 | 030510 | Key | 1 | |
| 134 | 030150 | Belt Drive | 1 | |
| 135 | 030170 | Bush Pulley | 1 | |
| 136 | 030190 | Pulley Driven | 1 | |
| 137 | 031170 | Screw | 2 | |
| 138 | 030460 | Bearing | 3 | |
| 139 | 030500 | Clip | 1 | |
| 140 | 030120 | Balance Weight | 1 | |
| 141 | 030080 | Holder Sanding Pad | 1 | |
| 142 | 030410 | Plate Cover | 1 | |
| 143 | 030110 | Bush Eccentric | 1 | |
| 144 | 030440 | Cap Retaining | 1 | |
| 145 | 030780 | Screw | 1 | |
| 146 | 030520 | Spring Sanding Pad | 2 | |
| 147 | 980629 | Washer | 1 | |
| 148 | 030830 | Screw | 2 | |
| 149 | 010680 | Pin Cotter | 1 | |
| 150 | 030850 | Nut | 2 | |
| 151 | 030860 | Washer | 3 | |
| 152 | 030100 | Pin | 2 | |
| 153 | 030600 | Spring Plunger | 2 | |
| 154 | 030840 | Screw | 2 | |
| 156 | 031650 | Knob Assembly | 1 | |
| 157 | 031370 | Hook and Loop Pad | 1 | |
| 170 | 07038 | Disposable Paper Dust Bag HT7/HTF Pack 2 (box 25) | 25 | |
| 170 | 07040 | Disposable Paper Dust Bag HT7/HTF (box 50) | 50 | |
| 180 | 031390 | Owners Manual & Operating Instructions | 1 | |
| 250 | 011740 | Service Tool - Pinion & Pulley Fitting/Removal | 1 | |
| 250 | 031490 | Service Tool - Lever Block Holder HTF | 1 | |
| 250 | 031610 | Service Tool - Jacking Bolts HTF | 1 | |

Hire Technicians Group Ltd

Chalk Hill House, 8 Chalk Hill, Watford, Herts WD19 4BH, UK

T: +44 (0)1923 332424 F: +44 (0)1923 332425 E: sales@hiretech.biz