



HT8-1.2 CIRCUIT DIAGRAM



FITTING A REPLACEMENT SWITCH

INSTRUCTION FOR NORTH AMERICA



INSTRUCTION FOR EEC, AUS, NZ

